

SECTION 1

GENERAL INFORMATION

TABLE OF CONTENTS

Section 1 - General Information.....1-1
 Introduction/Address/Phone #'s1-2
 Important Safety Information.....1-3
Section 2 - Component Information.....2-1
 Door & Drawer Assemblies2-2
 Drawer Removal & Installation.....2-3
 Electronic Control System2-4
 Temperature Settings.....2-4
 Control Panel Removal.....2-4
 Control Board/Microprocessor.....2-6
 Location & Access.....2-6
 Zone Thermistors2-7
 Location & Removal.....2-7
 Air Baffles2-9
 Location & Removal.....2-9
 Evaporator Sump.....2-11
 Sump Area Access.....2-11
 Sump Component Removal.....2-12
 Defrost System2-13
 Lighting2-13
 Electronic Control Summary.....2-14
 Electrical System Overlay.....2-16
 Unit Tray Compartment2-17
 Unit Tray Assembly.....2-17
 Master Power Switch.....2-17
 Icemaker Solenoid Valve.....2-17

 12-Volt Transformer2-18
 Evap. Sump Drain Tube Heater.....2-18
Section 3 - Air Flow3-1
 700TR.....3-2
 700TC/I3-2
 700TF/I.....3-3
 700BR.....3-3
 700BF/I.....3-3
Section 4 - Parts Lists w/Exploded Views.....4-1
 700TR.....4-2
 700TC/I4-8
 700TF/I.....4-14
 700BR.....4-20
 700BF/I.....4-26
Section 5 - Troubleshooting Guides.....5-1
 General5-2
 Door Closing Check & Repair.....5-9
 TC/I Air Seals.....5-10
 Sealed System.....5-11
 Icemaker, Modular5-14
Section 6 - Technical Data6-1
Section 7 - Wiring Diagrams/Schematics.....7-1
 700TR.....7-2
 700TC/I7-4
 700TF/I.....7-6
 700BR.....7-8
 700BF/I.....7-10

INTRODUCTION

This manual has been prepared for your use in servicing Sub-Zero 700 Series units. Included are helpful facts on service, troubleshooting, specifications and parts information.

It is important that you familiarize yourself with the product as much as possible before initiating any maintenance, troubleshooting or repairs.

IMPORTANT: Always refer to the 700 Series Parts Price List Book for any parts that have been superseded by serial number.

The model and serial number tag is located above the top left drawer slide assembly. Always have this information available when ordering parts.

We encourage you to review this manual and get acquainted with the information. If you should have any questions regarding this equipment, please contact:

Sub-Zero Freezer Co., Inc.
Service Department
PO Box 44130
Madison, WI 53744-4130
1-800-222-7820
or
1-800-919-8324

Technical Assistance Facsimile
608-271-5692

Parts/Warranty Claims Facsimile
608-271-0704

Office Hours
7:00 AM to 7:00 PM Central Time
Monday - Friday

This manual is designed to be used by Authorized Service Personnel only. Sub-Zero Freezer Co., Inc. assumes no responsibility for any repairs made on Sub-Zero refrigeration units by anyone other than Authorized Service Technicians.

IMPORTANT SAFETY INFORMATION

At right are the Product Safety Labels used in this manual. The “Signal Words” used are WARNING or CAUTION.

Below the Product Safety Labels is a description of the precautions to be taken when the signal word is observed.

When reviewing this manual, please note these different safety labels places in areas where awareness of personal safety and product safety should be taken.

▲WARNING
Indicates that hazards or unsafe practices could result in severe personal injury or death.

▲CAUTION
Indicates hazards or unsafe practices could result in minor personal injury or product and/or property damage.