



ELECTRONIC CONTROL TERMINOLOGY & COMPONENT DESCRIPTIONS

The electronic control system monitors, regulates and controls a variety of functions. It also displays temperature readings, ice maker system operational status, possible problems with the unit and door ajar alarm status. The table below defines some basic electronic control system terminology and describes some of the electronic control system components. An understanding of the following information is needed in order to comprehend the input operations and functions of the electronic control system.

Term/Component	Definition / Description
Control Board	The printed-circuit board (PC Board) contains the microprocessor, relays and electrical connections which control and monitor all functions and operations of the appliance.
Microprocessor	An electrical component on the control board which receives electrical signals from other components, processes that information, then sends an electrical signal to the relays on the board to open or close, and other electronic components in the unit to switch on or off.
Relay	The electrical components on the control board which switch other components in the unit ON and OFF when instructed to do so by the microprocessor.
LCD (Liquid Crystal Display)	That part of the control board seen at the control panel which displays zone temperatures, service indicator, door ajar alarm bell & ice indicator.
Control Panel Assembly	The information input and read-out area of the electronic control system, located at the top of the upper Compartment.
Membrane Switch	An integral part of the control panel assembly, which consists of the function keys used for all input operations to the electronic control system.
Keys (Function Keys)	The buttons on the Membrane switch used for input operations. (The keys are: UNIT ON/OFF, ALARM ON/OFF, ICE ON/OFF, WARMER, COLDER)
Indicators	The words and numbers that are displayed at the control panel assembly. (Example: Temperature displays, alarm bell indicator, SERVICE indicator, and ICE system indicator)
Error Codes	The code numbers accompanied by the letters "EC" that appear on the LCD during diagnostic mode if the unit experienced specific problems related to electrical signals supplied by electrical components.
Display Units of Measure.....	Temperatures displayed at the LCD may be in fahrenheit units of measure (°F) or celsius units of measure (°C). A series of key strokes allows the temperature display units of measure to be switched to read as either °F or °C.
Set-Point	The desired zone temperature, established by pressing the COLDER or WARMER keys.
High Offset (Cut-in).....	As the zone air temperature cycles up and down, the high offset is the maximum zone temperature that the electronic control system will allow before calling for cooling.
Low Offset (Cut-out).....	As the zone air temperature cycles up and down, the low offset is the minimum zone air temperature that the electronic control system will allow before interrupting cooling.
Thermistor (Temperature Sensor)	A resistor with which resistance changes as the temperature around it changes. For electronic control system purposes, the microprocessor measures this resistance and displays it as a temperature reading at the LCD.
Variable Speed Compressor	A compressor that runs at varying speeds depending on the load detected by the compressor's inverter.



BASIC ELECTRONIC CONTROL SYSTEM

Input operations for the electronic control system are performed at the control panel (located at the top of the upper compartment), with monitoring, regulating and controlling functions taking place at the control board (located directly behind the control panel). Temperatures and possible problems with the unit are illuminated in the control panel at the LCD. This page illustrates a basic 700 Series electronic control system (Model 700TCI-3 used, See Figure 3-1). The entire electronic control system is described in greater detail on the following pages.




Figure 3-1. Basic 700TCI-3 Electronic Control System Diagram



CONTROL BOARD LAYOUT AND SUMMARY TABLE

The electrical connection points on the control board are labeled alphanumerically. These labels correspond with the alphanumeric control board summary table, located on the wiring diagrams. By referencing the summary table, it is possible to identify which components are connected at which connection points on the control board. Below is a layout diagram of the control board, and a copy of a summary table. (See Figures 3-2 and 3-3)

NOTE: All components on the control board are non-replaceable. If a problem with the control board is identified, the complete control board must be replaced.




Figure 3-2. 700-3 Tall Unit Control Board Layout

CONTROL BOARD SUMMARY				
	CIRCUIT	DESCRIPTION	FUNCTION	COLOR
		120 VOLT CIRCUITS		
E2	DEF HTR	DEFROST HEATER	POWERS DEFROST CIRCUIT	BLUE
E7	FCOMP	FRZ COMPRESSOR	POWERS FRZ COMPRESSOR (DRAWERS)	PURPLE
E10	L1	POWER IN	POWER INTO BOARD	BLACK
E6	RCOMP	REF COMPRESSOR	POWERS REF COMPRESSOR (DOOR)	GRAY
J7-1	C FAN	CONDENSER FAN	POWERS CONDENSER FAN	WHITE/RED
J7-2	E FAN	NOT USED		
J7-3	IACC	ICE MAKER ACC (FILL TUBE)	POWERS FILL TUBE HEATER AND ACCESSORIES	WHITE/BLUE
J7-4	LITES	LIGHTS	POWERS LIGHTS	YELLOW
J7-5	ICE	ICE MAKER	POWERS ICE MAKER	PINK
J7-6		NOT USED		
J7-7		NOT USED(NO PIN)		
J7-8	NEU	NEUTRAL	NEUTRAL INTO BOARD	WHITE
J4-1	F DR	DRAWER LIGHTS SENSE	SENSES IF EITHER DRAWER OPEN	ORANGE
J4-2	R DR	DOOR LIGHTS SENSE	SENSES IF DOOR OPEN	ORANGE
J4-3		NOT USED(NO PIN)		
J4-4		DEF SENSOR	SENSES WHEN DEF HEATER SHUTS OFF	GRAY/WHITE
J4-5		ICE MAKER VALVE SENSOR	SENSES WATER VALVE ACTIVATION	TAN
LOW VOLTAGE THERMISTOR CIRCUITS				
J1-1	EVAP FRZ	FRZ EVAP	SENSES FRZ EVAP TEMP (DRAWERS)	ORANGE/RED
J1-2	EVAP FRZ	FRZ EVAP	SENSES FRZ EVAP TEMP (DRAWERS)	BLUE/RED
J1-3	EVAP REF	REF EVAP	SENSES REF EVAP TEMP	ORANGE/YEL
J1-4	EVAP REF	REF EVAP	SENSES REF EVAP TEMP	BLUE/YELLOW
J1-5	REF	REF COMPARTMENT	SENSES REF CABINET TEMP	BLUE/WHITE
J1-6	REF	REF COMPARTMENT	SENSES REF CABINET TEMP	BLUE/WHITE
J1-7	FRZ	FRZ COMPARTMENT	SENSES FRZ CABINET TEMP (DRAWERS)	BLUE/BLACK
J1-8	FRZ	FRZ COMPARTMENT	SENSES FRZ CABINET TEMP (DRAWERS)	BLUE/BLACK

Figure 3-3. 700-3 Tall Unit Control Board Summary Table (700TC/I-3 Summary Table Shown)



CONTROL PANEL LAYOUT

Please note that an illustration of the 700TC/I-3 control panel is used in most cases for this section. (See Fig. 3-4)




Figure 3-4. 700-3 Tall Unit Control Panel Layout (700TC/I-3 Control Panel Shown)

BASIC ELECTRONIC CONTROL INPUT OPERATIONS

Following are illustrations which show the basic input operations performed at the control panel. Switching the unit ON and OFF, adjusting the set-point (temperature adjustments), switching the ice maker system ON and OFF, and enabling and disabling the door ajar alarm feature will be explained. *Please note that an illustration of the 700TC/I-3 control panel is used for most articles in this section, and in most cases Fahrenheit readings are shown.*

Unit ON/OFF

All units are shipped in OFF Mode. When power is supplied to the unit, a trace of the word "OFF" is visible on the LCD. By pressing and releasing the UNIT ON/OFF key (See Figure 3-5), power is allowed past the control board to the rest of the unit. This is indicated by the unit's lights energizing and LCD at the control panel illuminating with temperature readings.

NOTE: Whenever the unit is switched OFF using the UNIT ON/OFF key, a trace of the word "OFF" will be visible on the LCD as long as there is power to the unit.




Figure 3-5. 700-3 Tall Unit ON/OFF, Press UNIT ON/OFF Key

Adjusting Set-Point (Temperature Adjustment)

To adjust set-points, press WARMER or COLDER key on control panel in multiple key strokes until desired set-point is achieved (See Figure 3-6). One key stroke equals one degree change.

NOTE: The temperature range in a freezer zone is -5°F (-21°C) to +5°F (-15°C). The temperature range in a refrigerator zone is +34°F (+1°C) to +45°F (+7°C).

NOTE: The initial stroke of the WARMER or COLDER key will change the previous set-point by one degree.

NOTE: The set-point will be displayed on the LCD for 10 seconds after the last key stroke. After the 10 second delay, the zone temperature will be displayed. As the zone temperature changes, the temperature displayed on the LCD will change by no more than one degree per minute.




Figure 3-6. Adjusting Set-Point - Press WARMER or COLDER Key In Multiple Key Strokes

Icemaker System ON/OFF

When a unit first arrives in a home, the icemaker system is off. By pressing and releasing the ICE ON/OFF key, power is allowed to the icemaker system and "ICE" appears on the LCD (See Figure 3-7). To switch the icemaker system off, press and release the ICE ON/OFF key again and the "ICE" indicator disappears from the LCD, indicating the icemaker system is off.

NOTE: When in "Sabbath Mode," the icemaker system is deactivated. Sabbath Mode will be explained later.

NOTE: To allow ice to freeze fully and reduce effects of low water pressure, power to the icemaker system is interrupted for 45 minutes after each ice harvest. This can be bypassed for service purposes by switching the icemaker system OFF, then back ON with the ICE ON/OFF key.




Figure 3-7. Icemaker System ON/OFF - Press ICE ON/OFF Key

Door Ajar Alarm Feature (Δ) ON/OFF

All units are equipped with a door ajar alarm feature. To enable the door ajar alarm, press and release the Alarm Bell ON/OFF key on the control panel (See Figure 3-8). The bell indicator appears on the LCD indicating the alarm feature is active. With the alarm enabled, the bell indicator will flash and an audible alarm will beep whenever the door is left open for more than thirty seconds. To disable the door ajar alarm, press the Alarm Bell ON/OFF key again and the bell indicator disappears from the LCD, indicating the alarm feature is inactive.




Figure 3-8. Switching Door Ajar Alarm ON or OFF - Press (Δ) ON/OFF Key



UNIQUE ELECTRONIC CONTROL INPUT OPERATIONS

The following pages illustrate unique input operations performed at the control panel that you would not expect a customer to perform every day. The input operations described are: Temperature Unit Selection Mode, Sabbath Mode, Showroom Mode, Manual Zone Disable Mode and Manual Freezer Evaporator Defrost.

Temperature Units Selection Mode (Selecting Degrees Fahrenheit or Degrees Celsius Display)


The electronic control is initially set to display temperature in Fahrenheit (°F) units of measure. Units of measure can be converted from °F to °C (Celsius), and/or back again. This operation is called Temperature Units Selection.

NOTE: Temperature Units Selection must be performed within the first minute after switching the unit ON.


To convert temperature units of measure from Fahrenheit (°F) to Celsius (°C) readings, press and hold the door ajar alarm bell ON/OFF key and the UNIT ON/OFF key simultaneously for five (5) seconds, then release the keys (See Figure 3-9). " °C " will appear on the LCD indicating that temperatures will now be displayed in Celsius units of measure. To convert back to Fahrenheit units of measure, repeat the steps above (See Figure 3-10).

NOTE: Temperature Units Selection Mode will end ten (10) seconds after the last key stroke.

NOTE: Do not press and hold the UNIT ON/OFF key first, that will simply switch the unit OFF.



**Figure 3-9. Converting to Celsius Units of Measure (within first minute after switching unit ON)
Press and Hold the Door Ajar Alarm Bell Key and The UNIT ON/OFF Keys for Five (5) Seconds**



**Figure 3-10. Converting Back to Fahrenheit Units of Measure
(within ten (10) seconds of previous key stroke and/or within first minute after switching unit ON)
Press and Hold the Door Ajar Alarm Bell Key and The UNIT ON/OFF Keys**



Sabbath Mode

Sabbath Mode was incorporated into the electronic control system for the observance of certain religious days. Initiating Sabbath Mode disables the LCD, lighting system, ice making system and door ajar alarm feature.

To initiate Sabbath Mode, the unit must first be switched OFF using the UNIT ON/OFF key (See Figure 3-11), then press and hold the UNIT ON/OFF key until the LCD and lights switch OFF, approximately ten (10) seconds (See Figure 3-12). To return to normal operation, press and release the UNIT ON/OFF key.

NOTE: During Sabbath Mode, the LCD is disabled and set-points cannot be changed.

NOTE: During Sabbath Mode, the compartment thermistors still control compressor operation, except when high offset is reached, there is a random fifteen (15) to twenty-five (25) second delay before compressors are energized.




Figure 3-11. To Enter Sabbath Mode, Switch Unit OFF First




Figure 3-12. Then Press and Hold UNIT ON/OFF Key for 10 Seconds

Showroom Mode

Showroom Mode was incorporated into the electronic control system so that units could be displayed in a showroom setting. When in Showroom Mode, all cooling functions are disabled, but the lighting system remains active.

To initiate Showroom Mode, the unit must first be switched OFF using the UNIT ON/OFF key (See Figure 3-13), then press and hold either pair of WARMER and COLDER keys, then the UNIT ON/OFF key, then release all three keys (See Figure 3-14). To return the unit to normal operation, repeat the steps above.

NOTE: Always check set-points after returning unit to normal operation.

NOTE: It is possible to determine if a unit is in Showroom Mode by initiating Diagnostic Mode. If "Sr" is observed in the left temperature display area during Diagnostic Mode, the unit is in Showroom mode. Initiating Diagnostic Mode is covered later in this section.




Figure 3-13. To Enter (or Exit) Showroom Mode, Switch Unit OFF First




Figure 3-14. Then Press and Hold WARMER and COLDER Keys, Then the UNIT ON/OFF Key



Manual Zone Disable Mode

Manual Zone Disable Mode allows a customer or Service Technician to switch one zone off for interior cleaning, defrosting, or diagnostic purposes, while allowing the other zone to continue cooling.

To initiate Manual Zone Disable Mode, the unit must first be switched OFF using the UNIT ON/OFF key (See Figure 3-15), then press and hold the WARMER key for the zone being disabled, then the UNIT ON/OFF key, then release both keys (See Figure 3-16). The LCD will display "--" (double dashes) in place of temperature readings for the zone chosen, indicating all cooling functions for that zone are disabled. To return the unit to normal operation, repeat the steps above, or press UNIT ON/OFF key.

NOTE: Always check set-points after returning unit to normal operation.




Figure 3-15. To Enter (or Exit) Manual Zone Disable Mode, Switch Unit OFF First




Figure 3-16. Then Press and Hold WARMER Key for Zone Being Disabled, Then the UNIT ON/OFF Key.

Manual Freezer Evaporator Defrost

Manual Freezer Evaporator Defrost was incorporated into the electronic control to assist in servicing and diagnostics.

To initiate manual freezer evaporator defrost, press and hold the ICE ON/OFF key for five (5) seconds, then release the key. (See Figure 3-17).

NOTE: Manual Freezer Evaporator Defrost will not operate if unit is in Sabbath Mode.




Figure 3-17. Initiate Manual Freezer Evaporator Defrost - Press and Hold ICE ON/OFF key for 5 Seconds



FUNCTIONS OF THE ELECTRONIC CONTROL SYSTEM

The following pages explain monitoring, regulating and controlling functions of the electronic control system. In most cases signal traces of a model 700TCI-3 wiring schematic are used to show current flow for functions being explained.

Supply Power to the Lighting System

115 Volts AC are supplied to the lighting system through the control board when the unit is switched **ON** by pressing the UNIT ON/OFF key. With the doors open, the light switches allows power to the lights (See Figure 3-18).

NOTE: 115 Volt AC signal to the lights is monitored by the microprocessor to control the door ajar alarm feature.

NOTE: If in Sabbath Mode, th lighting system is disabled. Sabbath Mode will be covered later.




Figure 3-18. 700TC/I-3 Signal Trace Schematic of Lighting System

Monitor, Regulate and Display Compartment Temperatures

The temperature signal from the compartment thermistor is monitored by the microprocessor and then displayed on the LCD. Though the compartment air temperature does fluctuate, the LCD displays the average temperature (See Figure 3-19). When the compartment temperature reaches high offset, the microprocessor supplies power to the compressor and evaporator fan (See Figure 3-20). As the compressor and evaporator fan run, the compartment temperature drops. When the compartment temperature reaches low offset, the microprocessor interrupts power to the compressor and evaporator fan, cycling them off.

NOTE: If the average compartment temperature changes, the temperature displayed on the LCD will change by one degree per minute.




Figure 3-19. Average Compartment Temperature Displayed




Figure 3-20. 700TC/I-3 Signal Trace Schematic (High & Low Voltage) of Regulating Temperatures



Assist in Control of Variable Speed Compressors (700TF/I-3 Only)

As mentioned on the previous page, temperature signals from the thermistors in the compartment are monitored by the microprocessor and then displayed on the LCD.

When the compartment reaches high-offset (calling for cooling), an "ON" signal is sent from the control board to the compressor's inverter. The inverter (which is supplied with AC power at all times) then provide high DC voltage (3-phase, 50 - 150 Hz), outputs to the compressor. The inverter in turn senses the compressor load. If the compressor load is high, the speed command from the inverter will be for high speed compressor operation; if medium compressor load, speed command from the inverter will be for medium speed; if low compressor load, speed command from the inverter will be for low speed. If/when the compartment reaches low-offset, an "OFF" signal is sent to the inverter, which then cuts DC power to the compressor.

NOTE:

- The variable speed compressor, evaporator fan and the condenser fan will run a great majority of the time. This is normal. These components will only cycle off during defrost and may also cycle off for short periods of time if the ambient temperature is low enough.
- Initial speed command from an inverter to a compressor are always for High speed.




Figure 3-21. 700TF/I-3 Signal Trace Schematic of Variable Speed Compressor Operation

Control Condenser Fan Run

In all models except the 700TF/I-3, the microprocessor senses the 115 volt output supplied to both compressors. If either compressor is running, a signal is sent to the condenser fan relay on the control board to close, supplying power to the condenser fan. If both compressors are off, the condenser fan is off. (See Figure 3-22)

NOTE: There is only one compressor on the model 700TF/I-3. The condenser fan cycles with this single compressor, which along with the evaporator fan, will cycle off during defrost and may also cycle off for short periods of time if the ambient temperature is low enough.




Figure 3-22. 700TC/I-3 Signal Trace Schematic (High Voltage) of Condenser Fan Operation



Monitor and Control Refrigerator "Fan-Assisted, Off-Cycle Defrost"

Temperature signals from refrigerator evaporator's thermistor's are observed by the microprocessor. During off cycle defrost, if a refrigerator zone temperature reaches high offset (calling for cooling) before evaporator temperature rises to 38°F (3°C), no power will be supplied to the compressor. But, the zone evaporator fan will switch ON. Once the evaporator temperature reaches 38°F (3°C), normal cooling functions begin. (See Figure 3-23).

NOTE: If refrigerator compartment thermistor is faulty, compressor operation defaults to 20 minutes ON, 40 minutes OFF cycling, EE appears in left of LCD, SERVICE will flash and Error Code 05 will be logged.

NOTE: If evaporator thermistor is faulty, the compressor will not energize until zone air temperature exceeds high offset by 5°F (3°C). SERVICE flashes and Error Code 06 is logged.

NOTE: When in Sabbath Mode, the refrigerator compartment thermistor still controls compressor operation, except there is a random 15 to 25 second delay before the compressor is energized.




Figure 3-23. 700TC/I-3 Signal Trace Schematic (High & Low Voltage) of Refrigerator Off-Cycle Defrost



Monitor and Control Freezer “Adaptive Defrost”

Initially the freezer compressor will cycle-run for twelve hours (twenty-four hours in the model 700TF/I-3), after which the microprocessor sends the signal to the defrost relay on the control board to close. This supplies power to the defrost heater, and the compressor is switched off (See Figure 3-24). With the “Adaptive Defrost” technique, the length of time that the heater actually stays on to defrost the evaporator and satisfy the defrost terminator is observed by the microprocessor. The microprocessor then determines the number of hours before the next defrost. If the heater stays on for a shorter time than specified, the microprocessor increases the next defrost interval. If the heater stays on longer than specified, the electronic control decreases the next defrost interval. This is an ongoing process whereby the defrost time and the defrost interval will vary by unit use.

NOTE: A five (5) minute time delay/dwell follows all defrosts, except in the model 700TF/I-3 where the delay/dwell is ten (10) minutes. The drain trough heater is energized during defrost and the delay/dwell period.

NOTE: The minimum defrost interval is six (6) hours; The maximum defrost interval is eighty (80) hours; the maximum defrost duration is twenty-five (25) minutes.

NOTE: If the defrost sensing line is open, defrost operation defaults to 25 minute defrost time / 6 hour build time, and Error Code 22 is logged. If the evaporator thermistor detects an under-heat or overheat situation at the same time, Error Codes 20 or 23 is logged, respectively.

NOTE: During defrost, the displayed temperature is locked.




Figure 3-24. 700TC/I-3 Signal Trace Schematic (High Voltage) of Freezer Adaptive Defrost



Monitor Compressor Run Duration, Displays If Service is Needed

In all models except the 700TF/I-3, the microprocessor observes the changing state of the compressor relays to determine the length of compressor run time (See Figure 3-25). If a compressor runs 100% (Fre = 6 hours / Ref = 4 hours), an error code is logged (EC 40 / EC 50, respectively), and defrost is initiated, but SERVICE will not flash.

If several 100% run periods occur, and the compartment temperature does not fall to at least the set point / low off-set temperature average (and the door is not opened during the last run period), then SERVICE will flash along with the error code (See Figure 3-26).

NOTE: To clear a flashing SERVICE and EC, the problem must be corrected, then switch the unit off then back on and/or press the Bell ON/OFF key for 15 seconds. Failure to clear an error code will cause SERVICE to display constant once Diagnostic Mode is initiated.

NOTE: If the unit is ever switched OFF then back ON, the compressor will not energize for at least 3 minutes. This 3 minute minimum OFF time is used to protect the compressor and its electricals.




Figure 3-25. 700TC/I-3 Signal Trace Schematic (High Voltage) of Compressor Electrical System




Figure 3-26. "SERVICE", "40" or "50" and "EC" Flashing = Several Excessive Compressor Run Periods

Monitor Icemaker System and Display If Service is Needed

The microprocessor observes the 115 Volts AC supplied to the icemaker water valve solenoid. If the solenoid is energized for more than 15 seconds, power to the icemaker system is disabled for 24 hours (See Figure 3-28), and an error code is logged (EC 30). If this happens five consecutive times, ICE and SERVICE on the LCD will flash (See Figure 3-29), and the ICE ON/OFF key will be disabled.

NOTE: To clear the ICE and SERVICE error indicators, and reactivate the ICE ON/OFF key, the problem must be corrected, then the unit must be switched OFF and back ON, and the Alarm key must be pressed for 15 seconds to clear the Error Code.

NOTE: To allow ice to freeze fully and reduce effects of low water pressure, power to the icemaker system is interrupted for 45 minutes after each ice harvest. This can be bypassed for service purposes by switching the icemaker system OFF, then back ON using the ICE ON/OFF key.

NOTE: When in Sabbath Mode, the icemaker system is disabled. Sabbath Mode will be covered later.




Figure 3-28. 700TC/I-3 Signal Trace Schematic (High Voltage) of Icemaker Electrical System




Figure 3-29. ICE & SERVICE Flashing = Solenoid Energized 15 sec., every 24 hrs., 5 consecutive times



POSSIBLE ERROR INDICATORS

These pages contain diagrams illustrating what a customer may see on the LCD if there is a problem with the unit.

NOTE: To clear indicators and error codes, problem must be corrected then press Bell ON/OFF key for 15 seconds.

NOTE: For thermistor errors described below, thermistor can be tested by submersing it in a glass of ice water for 2 to 5 minutes, then check for 30,000 to 33,000 ohms.

- For Models 700TC/I-3 and 736TC/I-3, See Figures 3-30 through 3-36
- For Model 700TR-3 and 736TR-3, See Figures 3-37 through 3-42
- For Model 700TF/I-3, See Figures 3-43 through 3-47




Figure 3-30. 700TC/I-3 & 736TC/I-3

“EE” at Left and “SERVICE” Flashing = Freezer Compartment Thermistor (or its Wiring) Fault




Figure 3-31. 700TC/I-3 & 736TC/I-3

“SERVICE” Flashing and “EE” at right = Refrig. Compartment Thermistor (or its wiring) Fault




Figure 3-32. 700TC/I-3 & 736TC/I-3

“SERVICE” Alone Flashing = Refrig. Evap. Thermistor (or its Wiring) Fault




Figure 3-33. 700TC/I-3 & 736TC/I-3

“40”, or “50” and “SERVICE” and “EC” Flashing = Excessive Compressor Run




Figure 3-34. 700TC/I-3 & 736TC/I-3

“ICE” & “SERVICE” Flashing = Valve Solenoid energized > fifteen (15) Seconds, Icemaker System Disabled




Figure 3-35. 700TC/I-3 & 736TC/I-3

“SERVICE” Steady, not Flashing = Error Codes Observed in Diagnostic Mode, but not Cleared




Figure 3-36. 700TC/I-3 & 736TC/I-3

“ -- ” (Double Dashes) Displayed = Compartment Manually Disabled




Figure 3-37. 700TR-3 & 736TR-3
"EE" at Left and "SERVICE" Flashing = Lower Compartment Thermistor (or its Wiring) Fault




Figure 3-38. 700TR-3 & 736TR-3
"EE" at Right and "SERVICE" Flashing = Upper Compartment Thermistor (or its Wiring) Fault




Figure 3-39. 700TR-3 & 736TR-3
"SERVICE" Alone Flashing = Refrig. Evap. Thermistor (or its Wiring) Fault




Figure 3-40. 700TR-3 & 736TR-3
"50", "SERVICE" and "EC" Flashing = Excessive Compressor Run




Figure 3-41. 700TR-3 & 736TR-3
"SERVICE" Steady, not Flashing = Error Codes Observed in Diagnostic Mode, but not Cleared




Figure 3-42. 700TR & 736TR-3
"--" (Double Dashes) Displayed = Compartment Manually Disabled




Figure 3-43. 700TF/I-3

“EE” at Left and “SERVICE” Flashing = Freezer Compartment Thermistor (or its Wiring) Fault




Figure 3-44. 700TF/I-3

“ICE” & “SERVICE” Flashing = Valve Solenoid energized > fifteen (15) Seconds, Icemaker System Disabled




Figure 3-46. 700TF/I-3

“SERVICE” Steady, not Flashing = Error Codes Observed in Diagnostic Mode, but not Cleared




Figure 3-47. 700TF/I-3

“ -- ” (Double Dashes) Displayed = Compartment Manually Disabled



TROUBLESHOOTING INPUT OPERATIONS

The following few pages explain troubleshooting input operations performed at the control panel. The input operations described are Diagnostic Mode, Manual Component Activation Mode and Temperature Log Recall.

Diagnostic Mode

Initiating Diagnostic Mode allows the Service Technician to observe real-time temperature readings from all thermistors without temperature averaging. If errors were detected, "Error Codes" will also display during diagnostic mode.

NOTE: The model 700TF/I-3 has only one compartment thermistor and one evaporator thermistor.

NOTE: Since Diagnostic Mode varies only slightly between the different models, a diagram of the 700TC/I-3 control panel is used to illustrate Diagnostic Mode key strokes.

To initiate Diagnostic Mode, the unit must be ON, then press and hold either COLDER key, and press the UNIT ON/OFF key, then release both keys (See Figure 3-48). If no error codes are registered, the left display area will show real-time temperature of the thermistor, the right display area will show the thermistor location code, and all LCD indicators will illuminate. Pressing either COLDER key or either WARMER key while in Diagnostic Mode will toggle to the next or previous thermistor location, respectively. (See Figure 3-49, 3-50 and 3-51 and the Thermistor Location Code Tables on the next page)

NOTE: If the COLDER and UNIT ON/OFF keys are pressed and held for 10 seconds, Manual Component Activation Mode will be initiated (this is covered later in the section).

NOTE: Diagnostic Mode will end 20 seconds after the last key stroke.




Figure 3-48. Initiate Diagnostic Mode - Press and Hold Either COLDER Key, Then the UNIT ON/OFF Key ("F" Indicates Freezer Compartment)




Figure 3-49. Toggle Through Temperature Readings - Press Either COLDER Key ("r" Indicates Refrigerator Compartment)




Figure 3-50. Toggle Through Temperature Readings - Press Either COLDER Key ("FE" Indicates Freezer Evaporator)




Figure 3-51. Toggle Through Temperature Readings - Press Either COLDER Key ("rE" Indicates Refrigerator Evaporator)



700TC/I-3 & 736TC/I-3		700TR-3 & 736TR-3		700TF/I-3	
THERMISTOR LOCATION	CODE	THERMISTOR LOCATION	CODE	THERMISTOR LOCATION	CODE
Freezer Compartment	F	Lower Compartment	L	Freezer Compartment	F
Refrigerator Compartment	r	Upper Compartment	U	Freezer Evaporator	FE
Freezer Evaporator	FE	Lower Evaporator	LE		
Refrigerator Evaporator	rE	Upper Evaporator	UE		

Diagnostic Mode Indicators

If "EE" is observed in the left display area during Diagnostic Mode, the thermistor in that location is open or shorted, or there is a break in that thermistor's wiring (See Figure 3-52).




Figure 3-52. "EE" Observed in Diagnostic Mode = Thermistor Fault in Location Indicated by Code

If "Sr" is observed in the left display area when Diagnostic Mode is initiated, the unit is in Showroom Mode, which was explained earlier in this section (See Figure 3-53).




Figure 3-53. "Sr" Observed While in Diagnostic Mode = Unit is in Showroom Mode

If "EC" is observed in the right display area during Diagnostic Mode, the numbers at left are "Error Codes" (See Figure 3-55 and the Error Code Table on next page). Error Codes indicate problems registered by specific components. If error codes are registered, they will appear before temperature readings and can be toggled through with the temperature readings as described on the previous page.




Figure 3-55. "EC" Observed While in Diagnostic Mode = Error Code (See Table on Following Page)



Error Code Table	
CODE	INDICATION
05	Refrig. cabinet thermistor read open or shorted for 10+ seconds, or repeatedly read erratic temp's
06	Refrig. evaporator thermistor read open or shorted for 10+ seconds, or repeatedly read erratic temp's
07	Freezer cabinet thermistor read open or shorted for 10+ seconds, or repeatedly read erratic temp's
08	Freezer evaporator thermistor read open or shorted for 10+ seconds, or repeatedly read erratic temp's
20	Defrost under-heat with no voltage feedback through Gray/White wire at defrost start
21	Defrost overheat
22	No voltage feedback through Gray/White wire at defrost start
23	Defrost overheat with no voltage feedback through Gray/White wire at defrost start
24	Defrost Under-heat
30	Excessive Icemaker Water Valve Solenoid Activation (Exceeded 15 Seconds)
40	Excessive Freezer Compressor Run
50	Excessive Refrigerator Compressor Run

NOTE: The table above will be updated through addendums when subsequent software and electrical changes occur and more error codes are added.

Clearing Error Codes

If error codes are observed during Diagnostic Mode, a non-flashing SERVICE annunciator will appear on the LCD when Diagnostic Mode ends, indicating error codes are still registered (See Figure 3-56). To clear a non-flashing SERVICE annunciator and the error codes, the problem must be corrected and the unit must be ON. Then, the Bell ON/OFF key must be pressed and held for fifteen (15) seconds. The control will emit a short "beep" when the SERVICE annunciator and error codes are cleared. (See Figure 3-57)




Figure 3-56. Non-flashing SERVICE Annunciator after Diagnostic Mode = Error Codes were Registered




Figure 3-57. Clear Non-flashing SERVICE Annunciator - Press & Hold Bell ON/OFF Key for 15 Seconds



Manual Component Activation Mode

Manual Component Activation Mode allows a Service Technician to energize a cooling system for five minutes. When activated, the chosen zone's compressor and evaporator fan are energized along with the condenser fan. While in Component Activation Mode, the evaporator temperatures for that zone are displayed on the LCD. This also allows the Service Technician to check for proper voltage readings at the activated components without having to wait for the compartment to call for cooling.

To initiate Manual Component Activation Mode, the unit must be ON. With the unit ON, press and hold the desired zone COLDER key and the UNIT ON/OFF key for ten seconds (See Figure 3-58). The evaporator temperature for that compartment will be displayed in the left display area of the LCD and the right display area will show the thermostat location.

NOTE: If the COLDER and UNIT ON/OFF keys are pressed and held for less than 10 seconds, Diagnostic Mode will be initiated.

NOTE: It is possible to toggle through the other temperature readings as in Diagnostic Mode, but in this case the temperature readings will last for five minutes rather than twenty seconds.

NOTE: The compressor overload could prevent the compressor from energizing.

NOTE: Manual Component Activation Mode will end five minutes after it is initiated. It is possible to end this five minute run time and return to normal operation by switching the unit OFF then back ON. If this is done, note that the electronic control will observe a three minute minimum compressor OFF time when the unit is switched back ON. This is to protect the compressor and its electricals.




Figure 3-58. Initiate Manual Component Activation Mode - Press and Hold Desired COLDER Key and UNIT ON/OFF Key for 10 Seconds



Temperature Log Recall Mode

The electronic control system is equipped with a temperature history data storage system. This system logs/stores the average temperature of each individual thermistor every two hours, along with any event indicators (explained later in this section), that may have occurred. These two-hour periods are referred to as "indexes". Up to 168 indexes can be stored for each compartment, making it possible to observe the preceding fourteen days of the unit's temperature history (*each index equals 2 hour temperature average; 2 hours X 168 indexes = 14 days*). After 168 indexes are stored, each new index will bump the oldest index. Index number "1" being the most recent two-hour temperature average and index number "168" being the oldest. Accessing this temperature history data so it can be viewed on the LCD is accomplished by initiating Temperature Log Recall Mode.

There are two ways to initiate Temperature Log Recall Mode. One allows viewing of compartment temperature history only (see below), the other allows viewing of compartment temperature history and evaporator temperature history (see following page).

Initiate Temperature Log Recall Mode To View Compartment Temperature History Only - Begin with the unit ON. Now, press and hold the desired compartment WARMER key, then press the UNIT ON/OFF key, then release both keys (See Figure 3-59). The left display area on the LCD will show average compartment thermistor temperature and in the right display area will be the index number. The first index number will be "1", indicating the most recent two-hour temperature average. The right display area will also flash the thermistor location code at 3 second intervals (See Figure 3-60).




Figure 3-59. Initiate Temperature Log Recall Mode To View Compartment Temperature History Only - Press and Hold Desired WARMER Key, Then Press UNIT ON/OFF Key




Figure 3-60. Thermistor Location Code Flashes Every Three Seconds

To toggle up through the indexes (from 1 to 168), press the same WARMER key in multiple key strokes (See Figure 3-61). To toggle down through the indexes (from 168 to 1), press the corresponding COLDER key in multiple key strokes (See Figure 3-62).




Figure 3-61. Toggle Up Through Indexes - Press WARMER Key in Consecutive Key Strokes




Figure 3-62. Toggle Down Through Indexes - Press COLDER Key in Consecutive Key Strokes



Initiate Temperature Log Recall Mode To View Compartment and Evaporator Temperature History - Begin with the unit ON and in Diagnostic Mode (See Figure 3-63). While in Diagnostic Mode, toggle through the readings until the desired thermistor temperature is displayed on the LCD (See Figure 3-64). Now, press the WARMER key for that compartment and the UNIT ON/OFF key simultaneously (See Figure 3-65). The left display area on the LCD will show average thermistor temperature and in the right display area will be the index number "1" indicating the most recent 2-hour temperature average (See Figure 3-65). The right display area will also flash the thermistor location code at three second intervals (See Figure 3-66).




Figure 3-63. Initiate Diagnostic Mode - Press and Hold Either COLDER Key, then the UNIT ON/OFF Key




Figure 3-64. Toggle Through Temperature Readings - Press Either COLDER Key or Either WARMER Key Until Desired Thermistor Temperature is Displayed




Figure 3-65. Initiate Temperature Log Recall Mode To View Temperature History - Press and Hold Desired WARMER Key and UNIT ON/OFF Key




Figure 3-66. Thermistor Location Code Flashes Every Three Seconds

To toggle up through the indexes (from 1 to 168), press the same WARMER key in multiple key strokes (See Figure 3-67). To toggle down through the indexes (from 168 to 1), press the corresponding COLDER key in multiple key strokes (See Figure 3-68).




Figure 3-67. Toggle Up Through Indexes - Press WARMER Key in Consecutive Key Strokes




Figure 3-68. Toggle Down Through Indexes - Press COLDER Key in Consecutive Key Strokes



Possible Temperature Log Recall Mode Event Indicators

The diagrams below illustrate possible event indicators that may be observed while in Temperature Log Recall Mode. (See Figures 3-69 through 3-72)




Figure 3-69. "bl" Indicates Index is "blank" - No Temperature has Been Logged Yet (Only possible within first 14 days of unit operation, or after new control board is installed during service)




Figure 3-70. SERVICE Annunciator Illuminates - Indicates Unit was switched OFF During that Index Period by Pressing UNIT ON/OFF Key




Figure 3-71. Bell Illuminates - Indicates Power Failure / Interruption During that Index Period




Figure 3-72. Double Dashes (- -) Displayed Instead of Temperature for Several Consecutive Index Periods - Indicates Bad EEPROM on Control Board. Board Must be Replaced

NOTE: Double dashes will also be observed when in Manual Zone Disable Mode. Only when double dashes are observed in Temperature Log Recall Mode for several consecutive indexes should the control board be replaced.

NOTE: If Manual Zone Disable Mode has been activated during any of the 168 indexes, average temperatures will continue to be logged. No event indicator will appear with these temperatures.

NOTE: If the unit was in Showroom Mode during any of the 168 indexes, average temperatures will continue to be logged. No event indicator will appear with these temperatures.

NOTE: If the unit was switched OFF by pressing the UNIT ON/OFF key during any of the 168 indexes and there was still 115V AC supplied to the control board, the average temperatures will continue to be logged. This means temperatures would be expected to rise and the SERVICE annunciator would be present in all indexes in which the unit was OFF.

NOTE: Temperature Log Recall Mode will end 20 seconds after the last key stroke.



Temperature Log Index Chart

NOTE : The chart below applies to the hours in which the control has power. Temperature history data will only be stored when the control has 115V AC supplied to it. If power to the unit is interrupted, the average temperatures for that time period are stored with the event indicator. The temperature history data is stored in a non-volatile memory, so the data is not erased by a power failure, but actual time passage during the power failure will not be shown.

TEMPERATURE LOG INDEX CHART			
Index=	Hours Past	Index=	Hours Past
1 =	2 Hrs	43 =	86 Hrs
2 =	4 Hrs	44 =	88 Hrs
3 =	6 Hrs	45 =	90 Hrs
4 =	8 Hrs	46 =	92 Hrs
5 =	10 Hrs	47 =	94 Hrs
6 =	12 Hrs	48 =	96 Hrs (4 Days)
7 =	14 Hrs	49 =	98 Hrs
8 =	16 Hrs	50 =	100 Hrs
9 =	18 Hrs	51 =	102 Hrs
10 =	20 Hrs	52 =	104 Hrs
11 =	22 Hrs	53 =	106 Hrs
12 =	24 Hrs (1 Day)	54 =	108 Hrs
13 =	26 Hrs	55 =	110 Hrs
14 =	28 Hrs	56 =	112 Hrs
15 =	30 Hrs	57 =	114 Hrs
16 =	32 Hrs	58 =	116 Hrs
17 =	34 Hrs	59 =	118 Hrs
18 =	36 Hrs	60 =	120 Hrs (5 Days)
19 =	38 Hrs	61 =	122 Hrs
20 =	40 Hrs	62 =	124 Hrs
21 =	42 Hrs	63 =	126 Hrs
22 =	44 Hrs	64 =	128 Hrs
23 =	46 Hrs	65 =	130 Hrs
24 =	48 Hrs (2 Days)	66 =	132 Hrs
25 =	50 Hrs	67 =	134 Hrs
26 =	52 Hrs	68 =	136 Hrs
27 =	54 Hrs	69 =	138 Hrs
28 =	56 Hrs	70 =	140 Hrs
29 =	58 Hrs	71 =	142 Hrs
30 =	60 Hrs	72 =	144 Hrs (6 Days)
31 =	62 Hrs	73 =	146 Hrs
32 =	64 Hrs	74 =	148 Hrs
33 =	66 Hrs	75 =	150 Hrs
34 =	68 Hrs	76 =	152 Hrs
35 =	70 Hrs	77 =	154 Hrs
36 =	72 Hrs (3 Days)	78 =	156 Hrs
37 =	74 Hrs	79 =	158 Hrs
38 =	76 Hrs	80 =	160 Hrs
39 =	78 Hrs	81 =	162 Hrs
40 =	80 Hrs	82 =	164 Hrs
41 =	82 Hrs	83 =	166 Hrs
42 =	84 Hrs	84 =	168 Hrs (7 Days)
		85 =	170 Hrs
		86 =	172 Hrs
		87 =	174 Hrs
		88 =	176 Hrs
		89 =	178 Hrs
		90 =	180 Hrs
		91 =	182 Hrs
		92 =	184 Hrs
		93 =	186 Hrs
		94 =	188 Hrs
		95 =	190 Hrs
		96 =	192 Hrs (8 Days)
		97 =	194 Hrs
		98 =	196 Hrs
		99 =	198 Hrs
		100 =	200 Hrs
		101 =	202 Hrs
		102 =	204 Hrs
		103 =	206 Hrs
		104 =	208 Hrs
		105 =	210 Hrs
		106 =	212 Hrs
		107 =	214 Hrs
		108 =	216 Hrs (9 Days)
		109 =	218 Hrs
		110 =	220 Hrs
		111 =	222 Hrs
		112 =	224 Hrs
		113 =	226 Hrs
		114 =	228 Hrs
		115 =	230 Hrs
		116 =	232 Hrs
		117 =	234 Hrs
		118 =	236 Hrs
		119 =	238 Hrs
		120 =	240 Hrs (10 Days)
		121 =	242 Hrs
		122 =	244 Hrs
		123 =	246 Hrs
		124 =	248 Hrs
		125 =	250 Hrs
		126 =	252 Hrs
		127 =	254 Hrs
		128 =	256 Hrs
		129 =	258 Hrs
		130 =	260 Hrs
		131 =	262 Hrs
		132 =	264 Hrs (11 Days)
		133 =	266 Hrs
		134 =	268 Hrs
		135 =	270 Hrs
		136 =	272 Hrs
		137 =	274 Hrs
		138 =	276 Hrs
		139 =	278 Hrs
		140 =	280 Hrs
		141 =	282 Hrs
		142 =	284 Hrs
		143 =	286 Hrs
		144 =	288 Hrs (12 Days)
		145 =	290 Hrs
		146 =	292 Hrs
		147 =	294 Hrs
		148 =	296 Hrs
		149 =	298 Hrs
		150 =	300 Hrs
		151 =	302 Hrs
		152 =	304 Hrs
		153 =	306 Hrs
		154 =	308 Hrs
		155 =	310 Hrs
		156 =	312 Hrs (13 Days)
		157 =	314 Hrs
		158 =	316 Hrs
		159 =	318 Hrs
		160 =	320 Hrs
		161 =	322 Hrs
		162 =	324 Hrs
		163 =	326 Hrs
		164 =	328 Hrs
		165 =	330 Hrs
		166 =	332 Hrs
		167 =	334 Hrs
		168 =	336 Hrs (14 Days)